

PDS #1085
PRODUCT INFORMATION

1191 Wheeling Road, Wheeling, IL 60090
Phone: 847-541-9000 Fax: 847-541-7549



PRODUCT: 98278

DESCRIPTION:

Valspar® Signature Colors® Faux Antiquing Glaze

FEATURES:

Ideal for use over Metallic Glaze to provide an aging effect. Use it over Porcelain Crackle Glaze to enhance the detail. Use on clean walls, ceilings, furniture, cabinets and trim. Practice your technique beforehand on a sample board.

COVERAGE:

100 - 250 sq. ft. (9.3 m² - 23.2 m²)

SURFACE PREPARATION:

Make sure surfaces are clean, dry and free of peeling paint. Use a base coat of Valspar paint. Allow 24 hours before applying glazes.

WORKING TIME:

Workable for up to 15 minutes. Mix with Clear Mixing Glaze for longer open time. Avoid drafts from fans, open windows, etc. to prevent premature drying. Wait 24 hours between coats.

APPLICATION:

1. Apply the base coat.
2. Apply Metal Glaze or Porcelain Crackle Glaze as outlined in the Valspar® Signature Colors® Faux How-to Guide. Allow to dry thoroughly.
3. Apply Antiquing Glaze using a clean, slightly damp, cotton rag. Apply to small areas in a circular motion, gently blending them together.

CLEANING UP:

Clean up with warm, soapy water.

PACKAGING:

Half Pints 4 Pack

CAUTIONS:

All Valspar® Signature Colors® Faux Finish products should be used in accordance with safe handling practices, including - Avoid contact with eyes and skin. Wash hands after use. Adult supervision is recommended when used by younger children.

DO NOT TAKE INTERNALLY
KEEP OUT OF REACH OF CHILDREN
For additional safety and chronic health hazard information, refer to the Material Safety Data Sheet for this product.

EMERGENCY MEDICAL TELEPHONE:

1-888-345-5732

Product Information Hotline:

1-888-313-5569

98278 Valspar Signature Colors Faux Antiquing Glaze

The data on this sheet represent typical values. Since application variables are a major factor in product performance, this information should serve only as a general guide. Valspar assumes no obligation or liability for use of this information. UNLESS VALSPAR AGREES OTHERWISE IN WRITING, VALSPAR MAKES NO WARRANTIES, EXPRESS OR IMPLIED, AND DISCLAIMS ALL IMPLIED WARRANTIES INCLUDING WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR USE OR FREEDOM FROM PATENT INFRINGEMENT. VALSPAR WILL NOT BE LIABLE FOR ANY SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES. Your only remedy for any defect in this product is the replacement of the defective product, or a refund of its purchase price, at our option.